

The Atomic Absorption Spares Kit includes

Burner Slot Cleaner



Retaining Nuts [3]



Impact Bead



Nebulizer Cleaning Wire [10 pieces]



nebulizer



Blow Out Plug & O-ring



Capillary Tubing [10 feet]

